


# VALVE CHANGER STOPPING UNITS REPAIR PARTS

Assembled Unit



**VALVE CHANGER STOPPING UNITS REPAIR PARTS**

CATEGORY	PART#	UNIT DESCRIPTION	LOC.	COMPONENT #	COMPONENT DESCRIPTION	QTY PER UNIT
STANDARD	PSVC 500	1/2" Valve Changer	1	DN 750	5/8", 1/2", 3/4" Upper Drive Nut for Valve Changer	1
			2	SLPWSHS	Bronze Spacer Ring 0.335", 1/2", 5/8", 3/4" Changer Stepped	1
			3	PSVC 750PR	3/4" Valve Changer Inner Pull Shaft	1
			4	PSVC 750T	1/2", 3/4" Valve Changer Outer Tube	1
			5	DC 375	Depth Collar .375 valve changer shaft	1
			6	OR 010	"O" Ring Size 010	2
			7	MSTS 1017250	1/4" M & F Miniature Ball Valve	1
			8	PSVC 750H	3/4" Valve Changer Housing	1
			9	OR 007	"O" Ring Inner Shaft for 0.335, 1/2', 3/4"	2
			10	EP 500	1/2" Steel Pipe End Plate	1
			11	NUT 832	Flex Lock Nut for 1/2", 3/4" Shafts	1
			12	PSVC 500A	1/2" .570 Sch 40 Rubber Plug	1
STANDARD	PSVC 750	3/4" Valve Changer	1	DN 750	5/8", 1/2", 3/4" Upper Drive Nut for Valve Changer	1
			2	SLPWSHS	Bronze Spacer Ring 0.335", 1/2", 5/8", 3/4" Changer Stepped	1
			3	PSVC 750PR	3/4" Valve Changer Inner Pull Shaft	1
			4	PSVC 750T	1/2", 3/4" Valve Changer Outer Tube	1
			5	DC 375	Depth Collar .375 valve changer shaft	1
			6	OR 012	"O" Ring Size 012	2
			7	MSTS 1017250	1/4" M & F Miniature Ball Valve	1
			8	PSVC 750H	3/4" Valve Changer Housing	1
			9	OR 007	"O" Ring Inner Shaft for 0.335, 1/2', 3/4"	2
			10	EP 750	3/4" End Plate	1
			11	NUT 832	Flex Lock Nut for 1/2", 3/4" Shafts	1
			12	PSVC 750A	3/4" Sch 40 Rubber Plugs	1
STANDARD	PSVC 1000	1" Valve Changer	1	DN 1000	1" Upper Drive Nut	1
			2	SLPWSHS1000	Bronze Slip Washer Stepped 1" Valve Changer	1
			3	PSVC 1000PR	1" Valve Changer Inner Pull Shaft	1
			4	PSVC 1000T	1" Valve Changer - Outer Tube	1
			5	DC 500	1/2" Depth Collar	1
			6	OR 014	"O" Ring Size 014	2
			7	MSTS 1017250	1/4" M & F Miniature Ball Valve	1
			8	PSVC 1000H	1" Valve Changer Housing	1
			10	EP 1000	1" End Plate (each)	1
			11	NUT 1032	Flex Lock Nut for 1" Changer	1
			12	PSVC 1000A	1" Sch 40/Sch 80 Rubber Plugs	1

**VALVE CHANGER STOPPING UNITS REPAIR PARTS**

CATEGORY	PART#	UNIT DESCRIPTION	LOC.	COMPONENT #	COMPONENT DESCRIPTION	QTY PER UNIT
STANDARD	PSVC 1250	1 1/4" Valve Changer	1	DN 1250	1 1/4", 1 1/2", 2" Upper Drive Nut	1
			2	SLPWSHS1250	Bronze Slip Washer Stepped 1 1/4" Valve Changer	1
			3	PSVC 1250PR	1 1/4" Valve Changer Inner Pull Shaft	1
			4	PSVC 1250T	1 1/4" valve changer outer tube	1
			5	DC 687	.687 Depth Collar	1
			6	OR 016	#016 O ring	2
			7	MSTS 1017250	1/4" M & F Miniature Ball Valve	1
			8	PSVC 1250H	1 1/4" Valve Changer Housing	1
			10	EP 1250	1 1/4" End Plate (each)	1
			11	NUT 250	1/4" Nylok Retainer Nut for 1 1/4" & 2" Valve Changer	1
			12	PSVC 1250A	1 1/4" Sch 40/Sch 80 Rubber Plugs	1
			STANDARD	PSVC 1500	1 1/2" Valve Changer	1
2	SLPWSHS1250	Bronze Slip Washer Stepped 1 1/4" Valve Changer				1
3	PSVC 1500PR	1 1/2" X Valve Changer - Inner Pull Rod				1
4	PSVC 1250T	1 1/4" valve changer outer tube				1
5	DC 687	.687 Depth Collar				1
6	OR 016	#016 O ring				2
7	MSTS 1017250	1/4" M & F Miniature Ball Valve				1
8	PSVC 1500H	1 1/2" Housing/Stuffing box				1
10	EP 1500	1 1/2" End Plate (each)				1
11	NUT 375	3/8" Nylok Retainer Nut				1
12	PSVC 1500A	1 1/2" Rubber Plugs				1
STANDARD	PSVC 2000	2" Valve Changer				1
			2	SLPWSHS1250	Bronze Slip Washer Stepped 1 1/4" Valve Changer	1
			3	PSVC 2000PR	2" Valve Changer pull rod x 2 ft	1
			4	PSVC 1250T	1 1/4" valve changer outer tube	1
			5	DC 687	.687 Depth Collar	1
			6	OR 016	#016 O ring	2
			7	MSTS 1017250	1/4" M & F Miniature Ball Valve	1
			8	PSVC 2000H	2" Housing / Stuffing Box	1
			10	EP 2000	2" End Plate (each)	1
			11	NUT 375	3/8" Nylok Retainer Nut	1
			12	PSVC 2000A	2" Rubber Plugs	1

**VALVE CHANGER STOPPING UNITS REPAIR PARTS**

CATEGORY	PART#	UNIT DESCRIPTION	LOC.	COMPONENT #	COMPONENT DESCRIPTION	QTY PER UNIT
UNDERSIZE	PSVC 1000HAYS	1" Valve Changer for Hays Valve	1	DN 1000	1" Upper Drive Nut	1
			2	SLPWSHS1000	Bronze Slip Washer Stepped 1" Valve Changer	1
			3	PSVC 1000HAYSPR	1" Hays valve changer inner pull rod	1
			4	PSVC 1000T	1" Valve Changer - Outer Tube	1
			5	DC 500	1/2" Depth Collar	1
			6	OR 014	"O" Ring Size 014	2
			7	MSTS 1017250	1/4" M & F Miniature Ball Valve	1
			8	PSVC 1000HAYSH	1" HAYS Valve Changer Stuffing Box/Housing	1
			10	EP 1000HAYS	1" Hays Valve Changer End Plates each	1
			11	NUT 1032	Flex Lock Nut for 1" Changer	1
			12	PSVC 1000HAYSA	1" Rubber Plug for HAYS Valve	1
			PE	PSVC 1000HW	1" Honeywell PE Riser Valve Changer	1
2	SLPWSHS1000	Bronze Slip Washer Stepped 1" Valve Changer				1
3	PSVC 1000PR	1" Valve Changer Inner Pull Shaft				1
4	PSVC 1000T	1" Valve Changer - Outer Tube				1
5	DC 500	1/2" Depth Collar				1
6	OR 014	"O" Ring Size 014				2
7	MSTS 1017250	1/4" M & F Miniature Ball Valve				1
8	PSVC 1000H	1" Valve Changer Housing				1
10	EP 1000	1" End Plate (each)				1
11	NUT 1032	Flex Lock Nut for 1" Changer				1
12	PSVC 1000HWA	1" Honeywell riser valve changer rubber, .850" X .500"				1
PE	PSVC 1250JMR	1 1/4" Valve Changer Honeywell Riser, Jomar Valve				1
			2	SLPWSHS1250	Bronze Slip Washer Stepped 1 1/4" Valve Changer	1
			3	PSVC 1250PR	1 1/4" Valve Changer Inner Pull Shaft	1
			4	PSVC 1250T	1 1/4" valve changer outer tube	1
			5	DC 687	.687 Depth Collar	1
			6	OR 016	#016 O ring	2
			7	MSTS 1017250	1/4" M & F Miniature Ball Valve	1
			8	PSVC 1250H	1 1/4" Valve Changer Housing	1
			10	EP 1250	1 1/4" End Plate (each)	1
			11	NUT 250	1/4" Nylok Retainer Nut for 1 1/4" & 2" Valve Changer	1
			12	PSVC 1250JMRA	1 1/4" Jomar/HoneyWell Replacement Rubber	1

**VALVE CHANGER STOPPING UNITS REPAIR PARTS**

CATEGORY	PART#	UNIT DESCRIPTION	LOC.	COMPONENT #	COMPONENT DESCRIPTION	QTY PER UNIT
DRESSER	PSVC 500DR	3/4" X 1/2" Valve Changer Dresser	1	DN 750DR	Upper Drive Nut .312" Tube, 3/4" & 1/2" Dresser, LLB 625	1
			2	SLPWSHDR	Bronze slip washer , stepped for .312 tube - Dresser Valves	1
			3	PSVC 750DRPR	3/4" Dresser 175 Valve Changer Pull Rod	1
			4	PSVC 750DRT	3/4" & 1/2" Dresser 175 Valve Changer Outer Tube .312" x 24"	1
			5	DC 375	Depth Collar .375 valve changer shaft	1
			6	OR 010	"O" Ring Size 010	2
			8	PSVC 750DRH	Housing for 3/4" and 3/4"x1/2"Dresser 175 Valve Changer	1
			9	OR 007	"O" Ring Inner Shaft for 0.335, 1/2', 3/4"	2
			10	EP 500DR	End Plate for 3/4" x 1/2" Dresser	1
			11	NUT 832	Flex Lock Nut for 1/2", 3/4" Shafts	1
			12	PSVC 500DRA	3/4" X 1/2" Valve Changer Dresser 175 Rubber Plug	1
			DRESSER	PSVC 750DR	3/4" Valve Changer Dresser	1
2	SLPWSHDR	Bronze slip washer , stepped for .312 tube - Dresser Valves				1
3	PSVC 750DRPR	3/4" Dresser 175 Valve Changer Pull Rod				1
4	PSVC 750DRT	3/4" & 1/2" Dresser 175 Valve Changer Outer Tube .312" x 24"				1
5	DC 375	Depth Collar .375 valve changer shaft				1
6	OR 010	"O" Ring Size 010				2
8	PSVC 750DRH	Housing for 3/4" and 3/4"x1/2"Dresser 175 Valve Changer				1
9	OR 007	"O" Ring Inner Shaft for 0.335, 1/2', 3/4"				2
10	EP 750DR	End Plate for 3/4" x 3/4" Dresser				1
11	NUT 832	Flex Lock Nut for 1/2", 3/4" Shafts				1
12	PSVC 750DRA	3/4" Valve Changer Dresser 175 Rubber Plug				1

**VALVE CHANGER STOPPING UNITS REPAIR PARTS**

CATEGORY	PART#	UNIT DESCRIPTION	LOC.	COMPONENT #	COMPONENT DESCRIPTION	QTY PER UNIT
CYLINDER	FBC 335	3/4" Valve Changer 1/2" PE Wayne Riser - PFSHA	1	DN 750	5/8", 1/2", 3/4" Upper Drive Nut for Valve Changer	1
			2	SLPWSHS	Bronze Spacer Ring 0.335", 1/2", 5/8", 3/4" Changer Stepped	1
			3	FBC 335PR	.335" Changer Pull Shaft	1
			4	FBC 335T	.335" Valve Changer Tube	1
			5	DC 375	Depth Collar .375 valve changer shaft	1
			6	OR 012	"O" Ring Size 012	2
			7	MSTS 1017250	1/4" M & F Miniature Ball Valve	1
			8	PSVC 750H	3/4" Valve Changer Housing	1
			9	OR 006	"O" Ring Inner Shaft for .335, 1/2" and 3/4" Valve Changer Shaft	2
			10	EP 335	.335" Round End Plate (each)	1
			11	NUT 632	Flex Lock Nut Shaved Down for 0.335" Shaft	1
			13	FBC 335A	.335" Round Rubber Plug	1
			CYLINDER	TSVC 580	5/8" Steel Tubing Stopper Valve Changer	1
2	SLPWSHS	Bronze Spacer Ring 0.335", 1/2", 5/8", 3/4" Changer Stepped				1
3	TSVC 580PR	5/8" tubing valve changer inner pull rod				1
4	PSVC 750T	1/2", 3/4" Valve Changer Outer Tube				1
5	DC 375	Depth Collar .375 valve changer shaft				1
6	OR 012	"O" Ring Size 012				2
7	MSTS 1017250	1/4" M & F Miniature Ball Valve				1
8	PSVC 750H	3/4" Valve Changer Housing				1
9	OR 006	"O" Ring Inner Shaft for .335, 1/2" and 3/4" Valve Changer Shaft				2
10	EP 580	End Plate for 5/8" Steel Tubing Changer				1
11	NUT 832	Flex Lock Nut for 1/2", 3/4" Shafts				1
13	TSVC 580A	5/8" Tubing Stopper Rubber Plugs				1
ORING	PSVC 280	Valve Changer for Service Head Adapter 0.280"				9
ORING	PSVC 300	3/4" Valve Changer LYCD SHA 300" Port	9	OR 008	"O" Ring 0.300 Solid Shaft	6